Bluetooth Umbrella Instruction Manual



Button functions Power/answer call/hang off call/play/pause Volume +/Previous Volume -/Next

2. Instructions

2.1 Turn on device

Press power key over 3 seconds, the device will enter into matching connection mode with quick flashing of its blue LED light (If it is the first time to turn on power, just press the power key for more than 3 seconds until quick flashing of the blue LED light. If the light is slow flashing, continuously press the power key to turn off and restart the device.

2.2 Matching connection

Switch on the mobile phone bluetooth, click the scan search button and find "Umbrella BT"; Click it; if the blue light becomes slow flashing then it is successfully connected.

Matching Note: If the matching connection is done before, then all you need to do is just to press the power key for 2 seconds and then you can move your finger away. The device will automatically recall the previous device for automatic connection.

- 3 Function specifications
- 3.1 Answer/Hang off a call

When there is an incoming call, both the device and the mobile phone will rang. Just a slight press of the power key and you can answer the call. When you speak, try to put your mouth close to the microphone. You can hang off the call with another press of the power key.

3.2 Play music in mobile phone

After the device is connected to a mobile phone, start the music player in the mobile phone and the device will play the music.

Long press PRE/V+, the volume will become bigger and bigger. Slightly press this button will return to previous music.

Long press NEXT/V-, the volume will become smaller and smaller. Slightly press this button will return to next music.

Slight press of power button can play/pause music.

- 4. Parameters
- 4.1 Recharge Voltage: DC 5V, 3 hours
- 4.2 Power supply: Built-in rechargeable lithium battery
- 4.3 Stereo amplifier THD=1% f=1KHz 2.0W
- 4.4 Supporting mobile phone with bluetooth version 3.0 and above
- 4.5 Device name: Umbrella BT
- 4.6 Timing for automatic shut-off of device: 8 minutes without matching
- 4.7 Device matching may fail due to different bluetooth brands.